



Round It™ Straightener/Rerounder

RCR3/4 #08226

RCR1 #08227

Use only with "K" Copper


The tool straightens and rounds anywhere along the length of Type K copper tubing. Work hardening and age hardening of copper can degrade the performance of this tool. The degree of initial out-of-roundness of tube can also degrade the tool's performance. Results may vary due to the above pre-existing conditions.

Rerounding

1. Place the tool over the copper tube and push the handles together.
2. Rotate the tool 90° and push the handles together.

Adjusting the tool

1. Loosen the Lock Screw.
2. Turn the Adjusting Screw clockwise to close the jaws. (Turn counter-clockwise to open the jaws.)
3. Tighten the Lock Screw. (Over tightening the Lock Screw will cause the handle to break in service.)



Reed Manufacturing Company
1425 West 8th St.
Erie, PA 16502 USA



Phone: 800-666-3691 or 814-452-3691
Fax: 800-456-1697 or 814-455-1697
www.reedmfgco.com

305-#58226



Round It™ Straightener/Rerounder

RCR3/4 #08226

RCR1 #08227

Use only with "K" Copper


The tool straightens and rounds anywhere along the length of Type K copper tubing. Work hardening and age hardening of copper can degrade the performance of this tool. The degree of initial out-of-roundness of tube can also degrade the tool's performance. Results may vary due to the above pre-existing conditions.

Rerounding

1. Place the tool over the copper tube and push the handles together.
2. Rotate the tool 90° and push the handles together.

Adjusting the tool

1. Loosen the Lock Screw.
2. Turn the Adjusting Screw clockwise to close the jaws. (Turn counter-clockwise to open the jaws.)
3. Tighten the Lock Screw. (Over tightening the Lock Screw will cause the handle to break in service.)



Reed Manufacturing Company
1425 West 8th St.
Erie, PA 16502 USA



Phone: 800-666-3691 or 814-452-3691
Fax: 800-456-1697 or 814-455-1697
www.reedmfgco.com

305-#58226