

# STEERING NOZZLE



1241



1245



1243













1246



1239



1240

 P/N	 Hose Con.	 Minimum/GPM	 Pipe Diameter	 L x W Dimensions	 lbs. Weight	 Rear Jets	 Front Jets	 Radial Jets	 # Tier
---	---	---	---	---	--	---	--	---	---

## 1239 Replacement Hose with Threaded Ends

1240	½"	12	3" - 8"	10.62" x 1.25"	0,22	4	4	---	2
1241	½"	12	3" - 8"	9.05" x 1.25"	0,55	6	4	---	2
1243	½"	12	3" - 8"	9.44" x 1.57"	0,99	6	4	---	2
1245	½"	12	3" - 8"	9.84" x 1.57"	1,54	3	4	3	2
1246	½"	12	3" - 8"	9.84" x 1.57"	1,43	3	4	3	2

## A nozzle for navigating

As the name suggest, the **Steering Nozzle** can be navigated into and through laterals and other branches. Simply twist your high-pressure hose to the left or right to direct the nozzle exactly where you want it to go.